



Nexohub II Smart
Bluetooth & Zigbee
Gateway User Manual

Scan the QR code below for an updated digital manual, more details, guides, FAQs, and other product resources for this device



<https://linkstyle.life/nex2h>

If you need any support, do not hesitate to reach out to us at:

email: support@linkstyle.life
voicemail: 1-888-419-4888


Index

| | |
|----------------------------------|----|
| A. Notice Before Use..... | 4 |
| B. Product Overview..... | 5 |
| C. Setup & Installation..... | 7 |
| D. Technical Specifications..... | 10 |
| E. Warranty & Support..... | 11 |

A. Notice Before Use

- When setting up a Bluetooth or Zigbee device with this gateway, keep the device, the gateway, and the Wi-Fi router all within close proximity during the setup process. You can relocate the smart device elsewhere within Bluetooth or Zigbee range after setup for regular use.
- Each Nexohub II supports up to 6 connected devices effectively. Do not exceed 6 devices to maintain stable connection.

A. Product Overview



A. Product Overview

- This smart gateway connects Zigbee and Bluetooth devices to your 2.4 GHz home Wi-Fi network to make them accessible via the internet from the Linkstyle app. This enables remote control and automation routines.

Package Includes:

Nexohub II Smart Gateway x 1

USB Power Cable x 1

User Manual x 1

B. Setup & Installation

Install the Linkstyle app

Scan the QR code below to download and install the Linkstyle app. Register a new account on the app if you do not have one.



*Alternatively, you can also search for "Linkstyle" on the Apple App Store or Google Play Store to find the app.

B. Setup & Installation (Continued)

***Important Note:

When registering an account in the Linkstyle app, be sure to set the region to United States of America.



Register

United States of America



Email Address

☐ I Agree [Privacy Policy](#) and [User Agreement](#)

B. Setup & Installation (Continued)

Add device to Linkstyle app

- Step 1: Connect your phone to your 2.4 GHz Wi-Fi network. Note: it will not work with a 5 GHz network.
- Step 2: In the Devices page of the Linkstyle app, tap the "+" button on the top right corner and tap "Add Device"
- Step 3: The app will automatically scan for devices nearby in setup mode. Once the the device is found, tap its icon and follow the on-screen instructions to complete setup.

C. Technical Specifications

| | |
|----------------------------|---|
| Model No. | SGDM3001 |
| Wireless Protocol | Wi-Fi, Zigbee, Bluetooth |
| Working Temperature | 14°F to 131°F (-10°C to 55°C) |
| Power Input | 5V 1.0A |
| Dimensions | 2.05in. x 2.05in. x 0.47in. (52mm x 52mm x 12mm) |
| Devices Supported | up to 6 connected devices |

D. Warranty & Support

Thank you for choosing Linkstyle. We are dedicated to providing innovative and convenient products for an enhanced lifestyle. This Product Warranty Agreement ("Warranty") applies to items purchased directly from Linkstyle.

Warranty Duration:

All products sold by Linkstyle come with a standard one (1) year warranty from the date of purchase, unless stated otherwise.

Warranty Coverage:

During the warranty duration, Linkstyle assures that the product will be free from defects in materials and workmanship when used under regular conditions.

Exclusions:

This Warranty does not cover the following:

- Damages due to misuse, neglect, or deviation from user instructions.
- Damages from natural disasters such as floods, fires, or accidents.
- Unauthorized repairs, modifications, or disassembling.
- Cosmetic damages like scratches, dents, or broken parts.

D. Warranty & Support

Filing a Warranty Claim:

- Reach out to Linkstyle Customer Support providing your proof of purchase, product details, and a comprehensive description of the issue.
- Our team will evaluate the claim and, if required, provide return shipping instructions.
- If the product is confirmed defective, Linkstyle, at its discretion, will repair or replace the item.

Limitation of Liability:

Linkstyle's liability is strictly limited to the repair or replacement of the product. Under no circumstances will Linkstyle be liable for any indirect, incidental, or consequential damages. The total liability shall not exceed the original purchase price of the product.

D. Warranty & Support (Continued)

Warranty Transferability:

This Warranty is solely for the original purchaser and cannot be transferred.

Governing Law:

This Warranty is governed by the laws of the country/state of purchase.

Disclaimer:

Apart from what's stated here, no other express or implied warranties apply, including implied warranties of merchantability or suitability for a specific purpose.

For any queries or concerns regarding our products or this Warranty, reach out to us at support@linkstyle.life.

Apple and Apple logos are trademarks of Apple, Inc., registered in the U.S. and other countries. App Store is a service mark of Apple, Inc.

Amazon, Alexa, and all related logos are trademarks of Amazon.com Inc. or its affiliates.

Google and Google Play are trademarks of Google LLC.

Other third-party brands and names are the property of their respective owners.

Linkstyle.life

Unlock the enchanted life!

